

Simply Cool Keyboard

The Simply Cool is a full size water-resistant and contaminant proof keyboard with tactile feedback keys. This sealed and rigid surface keyboard is value priced for industrial, marine, and medical use, as well as other applications where moisture and cleaning are a consideration. Because the Simply Cool is also quieter than "standard" keyboards, they are great for applications where noise generated from "key-clicks" is a problem. The Simply Cool is compatible with standard keyboard layouts and drivers are not needed.

Weight:

473.0 g (1.0 lb.)

Dimensions:

381 mm x 135 mm x 10.0 mm

15" x 5.3" x 0.4"

Cable length:

1.83 m (6')

Storage temperature:

-20 °C - 70 °C

-4 °F - 158 °F

Operating temperature:

0 °C - 70 °C

32 °F - 158 °F

Voltage:

5 Volt

Current input:

26 mA

Composition:

100% Silicone Rubber

PVC Cable

100% Latex free

System requirements:

USB interface

(Not Compatible with PS/2)

Number of keys:

104 US Layout keys with keypad.

Warranty period:

One year replacement warranty.

Specifications subject to change without notice

Installing Your Simply Cool Keyboard:

USB: Attach the keyboard cable to a USB computer port. (You do not have to turn off your computer. There is no software to install.)

You can email us at: info@mmimd.com

or call us at: (301) 341-4900

In Europe, contact +31-23-5450185

www.man-machine.com



Cleaning Instructions for Waterproof Keyboards and Mice:

- Clean the surface of the product by wiping, brushing, spraying or dipping it. Use only rags, sponges or soft bristle brushes. **DO NOT place the USB or PS/2 connector into the fluid.**
- Either wipe with dry cloth or allow to air dry.

Cleaning Instructions while the keyboard is plugged in:

- Lock the keyboard by pressing both Left and Right Control keys for about three seconds. After you finished cleaning press both Left and Right Control keys for 3 seconds to unlock the keyboard.

Disinfectants recommended by Man & Machine, Inc.:

- Chlorine based (max 10% solution) - Chlorox, Novalsan, etc.
- Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based - Cavicide, Isopropyl Alcohol, Medicide, etc.
- Oxidizing - Hydrogen Peroxide 3% Solution, Lifeguard Series, etc.
- Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, etc.
- Soap and water

DO NOT USE:

- Petroleum based cleaning fluids, such as Gasoline
- Acetone
- Over 10% bleach solutions
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT. MAN & MACHINE, INC. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE OR MMI PRIOR TO CLEANING.



Copyright Man & Machine, Inc. 2008