

U Cool Keyboard

The U Cool washable keyboard is Man & Machine's answer to people who want a water-resistant keyboard at an economical price. The U Cool is a less expensive alternative to our truly waterproof models. The U Cool has the same characteristics and feels as a standard desktop keyboard, and comes with all the passion, commitment and support that you expect with any of our "cool" products.

Weight:

539 g (1.2 lb.)

System requirements:

USB interface

Dimensions:

450.85 mm x 158.75 mm x 19.05 mm

(17.75" x 6.25" x 0.75")

Number of keys:

104 = US Layout with Windows™

Warranty period:

One-year limited warranty

Specifications subject to change without notice

Cable length:

1.44 m (4.75')


Voltage:

5 Volt

Installing Your U Cool Keyboard

USB: Attach the keyboard cable to a USB computer port. (You do not have to turn off your computer. There is no software to install.)

You can email us at: info@mmimd.com
or call us at: (301) 341-4900
In Europe, contact +31-23-5450185
www.man-machine.com



Cleaning Instructions for U Cool Keyboard:

1. Lock the keyboard by pressing both Left and Right Control keys for about three seconds.
2. Clean the surface of the product by wiping, brushing or spraying. Use only rags, sponges or soft bristle brushes. **DO NOT place the USB connector into the fluid.**
3. Either wipe with dry cloth or allow to air dry.
4. Keyboard can also be rinsed or submerged. After cleaning, drain, and turn upside down on dry towel and allow to air dry.
5. After you finished cleaning press both Left and Right Control keys for three seconds to unlock the keyboard.

Disinfectants recommended by Man & Machine, Inc.:

- Chlorine based (max 10% solution) - Chlorox, Novalsan, etc.
- Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based - Cavicide, Isopropyl Alcohol, Medicide, etc.
- Oxidizing - Hydrogen Peroxide 3% Solution, Lifegard Series, etc.
- Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, etc.
- Soap and water

DO NOT USE:

- Petroleum based cleaning fluids, such as Gasoline
- Acetone
- Over 10% bleach solutions
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

THESE INSTRUCTIONS AND RECOMMENDATIONS HAVE BEEN PREPARED TO ADVISE THE PROPER METHODS FOR CLEANING YOUR PRODUCT. MAN & MACHINE, INC. OR THE LOCAL DISTRIBUTOR CANNOT ASSUME ANY RESPONSIBILITY FOR THE APPLICATION OF THEM. IF THERE ARE ANY QUESTIONS, PLEASE CONTACT PLACE OF PURCHASE OR MMI PRIOR TO CLEANING.

MAN & MACHINE DOES NOT CONSIDER THE U COOL KEYBOARD TO BE A MEDICAL KEYBOARD FOR INFECTION CONTROL PURPOSES DUE TO THE INABILITY TO MECHANICALLY CLEAN ALL SURFACES AND AREAS ON THE KEYBOARD.